

D.RAK – ekvitermní křivky

Tabulka ekvitermních křivek

křivka	venkovní teplota																																				
	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	-1	-2	-3	-4	-5	-6	-7	-8	-9	-10	-11	-12	-13	-14	-15		
E0	24	26	28	29	30	31	32	33	34	34	35	35	36	36	37	37	37	38	38	38	38	39	39	39	39	39	39	40	40	40	40	40	40	40	40	40	
E1	25	27	29	30	32	33	34	35	36	37	38	39	40	40	41	42	42	43	44	44	44	45	45	46	46	47	47	48	48	48	49	49	49	49	50	50	
E2	25	28	30	32	33	35	36	38	39	40	41	42	43	44	45	46	47	48	49	50	50	51	52	53	54	54	55	56	56	57	58	58	59	59	60	60	
E3	25	28	31	33	35	37	38	40	41	43	44	46	47	48	50	51	52	53	54	55	56	58	59	60	61	62	63	64	65	65	66	67	68	69	70	70	
E4	25	29	31	34	36	38	40	42	44	46	47	49	51	52	54	55	57	58	60	61	62	64	65	67	68	69	70	72	73	74	75	76	78	79	80	80	
E5	26	29	32	35	38	40	42	44	47	49	51	53	54	56	58	60	62	63	65	67	68	70	72	73	75	77	78	80	81	83	84	86	87	89	90	90	
E6	26	30	33	36	39	42	44	47	49	51	54	56	58	60	62	65	67	69	71	73	74	76	78	80	82	84	86	88	89	90	90	90	90	90	90	90	
E7	26	30	34	37	40	43	46	49	52	54	57	59	62	64	67	69	71	74	76	78	80	83	85	87	89	90	90	90	90	90	90	90	90	90	90	90	90
E8	27	31	35	38	42	45	48	51	54	57	60	63	66	68	71	74	76	79	81	84	86	89	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90
E9	27	32	36	40	43	47	50	54	57	60	63	66	69	72	75	78	81	84	87	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90	90

Hodnoty v tabulce určují požadovanou teplotu topné vody v závislosti na venkovní teplotě a zvolené křivce E0 – E9.

